

ALPHA® OM-5100

FINE PITCH SOLDER PASTE

DESCRIPTION

ALPHA OM-5100 is a low residue, no-clean solder paste designed to maximize SMT line yields. The flux vehicle is rheologically formulated to provide excellent repeatability and resistance to environmental conditions. The ALPHA OM-5100 activation system has been optimized to enhance joint solderability, solderballs and other soldering defects while maintaining long term reliability. Minimizing defects requires robust and repeatable processes, equipment and materials.

FEATURES & BENEFITS

- · Quick start up and simple product substitution from current material
- Print Consistency: Lower "deposit to deposit" variation drives maximization of first pass print & reflow yields
- Print Repeatability: Lower variability after production dwells, ensuring a continuous production flow with minimized level of insufficient solder joints
- Solder Ball Reduction: Minimizing both mid chip and random solder balls helps to maximize reflow yields
- Excellent Solder Spread: Compatibility with a variety of pad and lead finishes drives overall cosmetics & yields up!
- Excellent response to pause performance, generating less defects due to start up
- High print speed, up to 150 mm/sec (6 inch/sec)
- Efficient activation system providing defect free soldering with a wide range of oven profiles
- Low residue level with minimal spread for reliable underfilling processes and results
- Excellent reliability properties, halide-free material

PRODUCT INFORMATION

Alloys: 62Sn/36Pb/2Ag, 63Sn/37Pb and 62.8Sn/36.8Pb/0.4Ag (NT4S, Anti Tombstoning Alloy)

Powder Size: Type 3, (25-45 μm per IPC J-STD-005)

Packaging Sizes: 500 gram jars, 6" and 12" cartridges, and DEK ProFlow® cassettes

Flux Gel: Available in 10cc and 30cc syringes for rework applications

APPLICATION

Formulated for both standard and fine pitch SMT stencil printing with apertures down to 0.3mm (12 mil) diameter and print speeds up to 150mm/sec (6"/sec) with standard stencil thickness of 0.100mm (4 mil) to 0.150mm (6 mil), particularly when used in conjunction with ALPHA Stencils.

SAFETY

While the ALPHA OM-5100 flux system is not considered toxic, its use in typical reflow will generate a small amount of reaction and decomposition vapors. These vapors should be adequately exhausted from the work area. Consult the MSDS for additional safety information, and for toxicity data on alloys containing lead and silver.

STORAGE

ALPHA OM-5100 should be stored in a refrigerator upon receipt at 0-10°C (32 - 50°F). Permit paste to reach room temperature prior to opening. This will prevent condensation of moisture on the solder paste. Other storage conditions are shown on page 2.

SM797-5 2014-09-29 an Alent plc Company

ALPHA Global Headquarters

300 Atrium Drive, Somerset, NJ 08873 USA • 1-800-367-5460 • www.alpha.alent.com

The information contained herein is based on data considered accurate and is offered at no charge. No warranty is expressed or implied regarding the accuracy of this data. Liability is expressly disclaimed for any loss or injury arising out of the use of this information or the use of any materials designated.



ALPHA® OM-5100

FINE PITCH SOLDER PASTE

_		CH	М	\sim		A	ГΛ
	Ε.	20		CA	LL	JΑΝ	IVÂ

OATE CODY	DECL!! TO	DDCCEDUDEC/DEAM DVC		
CATEGORY	RESULTS	PROCEDURES/REMARKS		
CHEMICAL PROPERTIES				
Activity Level	ROL0 = J-STD Classification (Corrosivity Cu Mirror Pass (L))	IPC J-STD-004		
	Copper Corrosion Test Pass	IPC J-STD-004		
Halide Content	Halide free (by titration). Passes Ag Chromate Test	IPC J-STD-004		
ELECTRICAL PROPERTIES	, , , , , , , , , , , , , , , , , , ,			
SIR (IPC 7 days @ 85° C/85% RH)	2.6 x 10 ⁹ ohms	Pass, IPC J-STD-004 {Pass = 1 x 10 ⁸ ohm min, uncleaned}		
SIR (Bellcore 96hrs@35°C/85%RH)	1.9 x 10 ¹² ohms	Pass, Bellcore GR78-CORE{Pass = 1 x 10 ¹¹ ohm min}		
Electromigration (Bellcore 500 hrs@ 65°C/85° RH)	initial 1.4 x 10 ⁹ ohms, final 9.3 x 10 ⁹ ohms	Pass, Bellcore GR78-CORE 62Sn/36Pb/2Ag {Pass= final > initial/10}		
PHYSICAL PROPERTIES	Using 90% Metal, Type #3 Powder			
Flux Residue Cosmetics	Clear, Colorless Flux Residue.	63Sn/37Pb alloy		
Tack Force vs. Humidity (24 hours)	Less than 1g/mm ² change at 25%,50% and 75% RH	IPC J-STD-005		
Viscosity	90% metal load designated M13 for printing.	Malcom Spiral Viscometer; J-STD-005		
Solderbáll	Pass < 10 count (62Sn/36Pb/2Ag, 63Sn/37Pb alloy)	Pass IPC J-STD-005		
Stencil Life	> 8 hours	@ 50%RH, 23°C (74°F)		
Observe	Hot Slump & Cold Slump Pass	IPC J-STD-005		
Slump	Pass	DIN Standard 32 513, 5.3		

ALPHA OM-5100 PROCESSING GUIDELINES								
STORAGE-HANDLING	PRINTING	REFLOW (See Figure #1)	CLEANING					
•Refrigerate to guarantee stability @ 0-10°C (32- 50°F)	STENCIL: Recommend ALPHA CUT or ALPHA FORM stencils @ 0.100 mm to 0.150 mm (4-6 mil) thick for 0.4-	ATMOSPHERE: Clean-dry air or nitrogen atmosphere.	ALPHA OM-510 residue is designed to remain on the board					
Shelf life of refrigerated paste is six months. Paste can be stored for 4 weeks	0.5mm (0.016"-0.020" pitch. Stencil design is subject to many process variables. Contact your local Cookson Electronics site for advice.	PROFILE: 63Sn/37Pb, 62Sn/36Pb/2Ag and 62.8Sn/36.8Pb/0.4Ag alloys: A straight ramp profile @ 0.8°C to 1.2°C per second ramp rate is recommended with a 30 to 90 sec TAL and 210 to 220°C peak. High density assemblies may require preheating as follows: -Ramp @ 1-2°C/sec. to 140-160°CDwell @ 140-160°C for 0-1.0 minutesRamp @ 1-2°C/sec to 210-220°C peak -Time above liquidus = 30-90 secs - Ramp down to R.T. @ 60-150°C/min.	after reflow. Misprints and soft flux residues remaining after rework may be removed with ALPHA Electronic Cleaners Bioact™ SC-10 & SC-10E and Hydrex™ SP Aqueous cleaners available from Alpha.					
at room temperatures up to 25°C (77°F).	SQUEEGEE: Metal. PRESSURE: 0.15 to 0.3 kg per cm (0.8-1.5 pounds per linear inch) of squeegee length. SPEED: 25mm to 150 mm (1 to 6 inches) per second. PASTE ROLL: 1.5-2.0 cm (0.6–0.8 inch) diameter and make additions when roll reaches 1-cm (0.4-in.) diameter. Maximum roll size will depend upon blade type. PRINT PUMP HEAD: ALPHA OM-5100 is suitable for use in both MPM RheoPump™ and DEK							
•When refrigerated, warm-up of paste container to room temperature for up to 8 hours. Paste must be ≥18°C (64°F)								
before processing. Verify paste emperature with a thermometer to ensure paste is at 18°C (64°F)								
or greater before setup. Printing can be performed at temperatures up to 28°C (82°F).								
•Do not remove worked paste from stencil and mix with unused paste in jar. This will alter rheology of unused paste.								
•These are starting recommendations and all process settings should be reviewed independently.	ProFlow™ systems.							



ALPHA® OM-5100FINE PITCH SOLDER PASTE

Figure #1: Typical Reflow Profiles

